









LEGEND			
AVR	- AUTOMATIC VOLTAGE REGULATOR	J_	- CONTROLLER CONNECTIONS
BA	- BRUSH ASSEMBLY	LOL	- LOW OIL LEVEL SWITCH
CB	- CIRCUIT BREAKER (MAIN OUTPUT)	R	- RESISTOR
CS	- CHOKE SOLENOID	SC	- STARTER CONTACTOR
FS	- FUEL SOLENOID	SM	- STARTER MOTOR
HOT	- HIGH OIL TEMPERATURE SWITCH	SP	- SPARK PLUG
IM	- IGNITION MODULE		